

OEM Installation Instructions

CAUTION

This symbol is used to indicate the presence of hazards that can cause minor personal injury or property damage.

1. Install alternator as shown in Figure 1:



Slip bushing located in rear mounting foot must be securely tightened against alternator mounting bracket on engine. Failure to do so can result in broken mounting feet or broken upper mounting bracket.


- a. Use hardened washers between aluminum surfaces and bolt heads and nuts.
- b. OEM units are shipped with pulley, hardened washer and locknut installed. Locknut should be torqued to 163 Nm/ 120 lb. ft.
- Follow vehicle manufacturer's recommendations for belt tension.
- 2. All cabling, wiring or conduit must be supported within 305 mm/12 in. of termination on alternator.
- 3. Choose wire gauge capable of handling maximum alternator output with no more than 0.4 V drop (28 V)/0.2 V drop (14 V) on each leg from alternator to battery.
- 4. Regulator is furnished with OEM units.

- 5. Make electrical connections to CEN regulator, using proper ring terminals.
 - a. Make sure alternator-to-regulator harnesses are plugged securely in regulator receptacles.
 - b. Connect IGN terminal on regulator to 28 V keyed ignition switch source. Torque #10-32 terminal nut to 3.4 Nm/30 lb. in.
- 6. Alternator electrical connections:
 - a. Connect battery positive cables from vehicle to alternator 28 V B+ and 14 V B+ terminals. Torque both 0.50-18 UNC-2A terminal bolts on alternator to 23 Nm/17 lb. ft.




B+ cables must be supported by cable clamps within 12" of both B+ output terminals to avoid premature failure of B+ output terminals. CEN recommends using cable clamps attached to alternator anti-drive end housing for support.

b. Connect ground cable from vehicle to alternator B– terminal. Torque 0.3750-16 UNC-2A
 B– terminal bolt on alternator to 23 Nm/
 17 lb. ft.



Alternator 14 V/ 28 V B+ Terminal Studs and Alternator B- Terminal Stud






Figure I - C725 Alternator Installation Details

If you have questions about your alternator or any of these instructions, or if you need to locate a Factory Authorized Service Dealer, please contact us at:

C. E. Niehoff & Co. • 2021 Lee Street • Evanston, IL 60202 USA